

- 1: As above 3D drawing to put all sectional material well, according to the hole in the back of the screen to determine the corresponding position.
- 2: fixing each connection with a corner code.





3: fixing the Angle iron on the vertical bar.



- 4: fixing all spliced shelves on the wall.
- 5: screwing all adjusting screws on the hook.





6: attaching all hooks to the screen



7: hanging all screens in accordance with order from bottom to top, and adjust the gap by adjusting screws